



Final






Step 1:

Doodle the strap by according to the size of your phone.




Following the depth of your phone to doodle the strap.



Step 5:
Left the depth space to put your phone in.



Doodle the front side of the phone strap and left the area for showing the phone screen.



Cut out the plastic for the phone screen depending on the size of your phone.



Step 6:

Mend both sides of the strap next to the main phone strap.





Mend prefectly for the both sides of the phone strap.




Step 8:

Decorate the pattern you want on the strap.



Buy the velcro for sticking on the both sides of the strap.



Measure the width of your arm and adjust the length of velcro for sticking on the strap.



